




# Scan 80 - Spare Parts




High Top, complete  
51053138 (Black)  
51053782 (White)



High Top for corner instal., complete  
51053140 (Black)  
51053783 (White)




Burn plate kit, complete  
51053154




Cover for top outlet  
51053201 (Black)  
51053785 (White)




Low top  
51053200 (black)  
51053781 (white)



Heat accumulation stones  
51049926



Connecting piece for tube outside  
51053167




Screws for connecting piece  
51053238

Gasket for flue outlet  
51046849



Rear cover, complete  
51053179 (Black)  
51053787 (White)



Door, Complete  
51053236

Vertical cover kit, left  
51053160

Glass Gasket  
AL  
51053223

Screw kit  
51053327


Top door list kit  
51053183

Glass list, top or bottom  
51053185

Inside cover for burnchamber kit  
51053212




Cover for flue outlet  
51046855




Bauart kit  
51053157



Guide for baffle unit  
51053210



Ash drawer  
51053026



Cast Iron grate  
51053148



Gasket for cast iron bottom  
51050570




Secondary air handle  
51053159

Primary air handle  
51053158


Cast iron bottom  
51053147




Front glass kit  
51053145



Vertical cover, Kit, Right  
51053166




Closing mechanism kit  
51053186




Hook  
Incl. Pinol screw  
50006110



Closed base, complete  
51053156 (Black)  
51053784 (White)



Base with door, complete  
51053155



Glass list, top or Bottom  
51053185

Pin  
51053747

Shaft + Pin, kit  
51053231

Bottom door list, kit  
51053184

Door handle, kit  
51053216

Push out mechanism, kit  
51053213


Door trim, left  
51053234

Door trim, center  
51053235

Small floor plate  
Clear glass: 50052370  
Smoked glass: 50052364



Large floor plate  
Clear glass: 50052372  
Smoked glass: 50052371



Adjustment screws kit  
M8x30  
51046856

